

Installation Manual

ALTH0771-5WY

Safety Rules (Attention):


Do not install the LED Downlights near flammable liquid, materials or surfaces.
Do not subject the LED Downlights to excess weight.
Avoid looking directly into the LED light beam at close range.
Clean, when needed, the front transparent cover with a dry cloth. Remove any dirt only with water and alcohol free cleaning products.
Operation in general ambient temperature up to 35.
PNY is not responsible for any damage or injury caused by incorrect or improper use of the product.



Safety Rules (Attention):

Before installation or maintenance, make sure electricity is switched off at the mains.
Install and operate in places where there is sufficient airflow to keep the module to acceptable temperature levels.
Cut correct size hole in ceiling given the dimensions below.
Make sure the correct driver is used.
Make sure the driver lies adjacent to the fitting.
Refer to driver specifications if you need relevant information.
Installation only by a qualified electrician.

Indicative Dimensions:



Note: Dimensions of drivers change depending on the model.
Please refer to the following pages of this user manual or contact your supplier for relative information.

Installation:

1



Attention


Before any maintenance switch off the main power.

ON


OFF

2

ALTH0771-5WY Ø55mm




3




4


4.1



4.2




5




Typical LED driver connections

Non-Dimmable



Dimmable



CAUTION!
For all connections make sure that the total load is within the safe operating area of the driver output.